

Client Information:

Client Name:		Phone:
Property Address:		
City:	State:	Zip code:
Report Contact (if different):		
<input type="checkbox"/> Email results to:		
Report Phone (if different):		

Site Information:

Are Map Apps/GPS sufficient for directions? Y / N: _____

Are the hose bibs frost free? Y / N / Unsure: _____

Is the property occupied? Y / N _____ Is there any treatment? Y / N / Unsure _____

Available access to: pumphouse/pressure tank/well? Y / N / Unsure: _____

Testing requested: Coliform/E.coli Nitrate Arsenic Lead Other: _____

Additional comments: _____

Payment Information:

- Client will mail in check
 Charge credit card (listed below)

Cardholder Name:	Account Number:
Expiration Date:	Billing Zip Code:

Self-Sampling Instructions:

- Fill out an Environmental Chain of custody form from our website with the address and sample collection information. List the second party and attach payment of **\$90.00, for standard turn-around**. Call our Customer Service Department for information and pricing on **rush** samples or sample pick-up.
- Collection of Coliform samples:
 - The Coliform test sample must be collected in the sealed, sterile bottle.
 - The sample must be collected from the source prior to any form of treatment, or after injection points where the treatment has been disabled or bypassed.**
 - Before collection, remove any strainers and wipe the faucet clean with an alcohol swab.
 - Run the water for 5 minutes or until it reaches constant temperature before collecting the sample.
 - Remove the sterile seal from the bottle and remove the cap.
 - Do not rinse out the bottle.**
 - Take care to not touch the inside of the cap or bottle. Fill the bottle between the 100 ml and the fill line.
 - Be sure to leave a 1-inch airspace. Do not overfill or overflow the bottle.**
- Fill both the Arsenic and Nitrate sample bottles.
- Arsenic, Nitrate, and Total Coliform samples must be received by the laboratory within **22 hours** of sample collection to allow adequate time for receipt and preparation within the required hold time.
- Samples must be kept cool, between 36° and 43°F. **Samples may be rejected if sampling instructions are not followed or if the microbiological sample has leaked, is not filled properly, and/or is over 30 hours old.**

The instructions noted on this form are for general guidance purposes only. Columbia Laboratories Inc. strongly recommends anyone taking samples, of any kind, research the applicable local and federal standards. Samples submitted to CL with testing requirements constitute an agreement for services in accordance with the current [terms and conditions](#) on our website. New accounts are accepted with full payment in advance by cash, check, Visa, or MasterCard.